



TYPICAL STARTER WIRING



MAKESAFE INTEGRATION W/ EXISTING STARTER



IF POWER IS SUPPLIED TO THE STARTER IN THIS CONFIGURATION, THE CONTACTOR WILL REMAIN IN THE CLOSED (ON) POSITION UNLESS THE OVERLOAD IS TRIPPED.

IMPORTANT NOTES:

1. ENSURE THAT THE CONTACTOR COIL VOLTAGE IS EQUAL TO THE LINE VOLTAGE.
2. ENSURE THAT THE CONTACTOR IS RATED FOR CONTINUOUS USE.
3. VERIFY PROPERLY SIZED CIRCUIT PROTECTION TO PROTECT THE WIRE BEING INSTALLED. THIS MAY INCLUDE A STARTER-INTEGRATED CIRCUIT BREAKER, FUSING, AND/OR BRANCH CIRCUIT PROTECTION.
4. ONLY USE THIS INTEGRATION FOR HARD-WIRING TO A MACHINE MOTOR. NEVER CONNECT A MAKESAFE UNIT DIRECTLY TO A MOTOR WITH A REMOVABLE PLUG.

THESE DESIGNS AND BOMS ARE THE CONFIDENTIAL PROPERTY OF MAKESAFE TOOLS, INC AND SHALL NOT BE DISTRIBUTED, SHARED, OR REPRODUCED WITHOUT EXPLICIT WRITTEN PERMISSION. MAKESAFE PRODUCTS ARE PROTECTED BY US PATENT NUMBER US10658953B2.
 MAKESAFE TOOLS, INC., SAN DIEGO, CA
 WWW.MAKESAFETOOLS.COM

PROJECT:	
CUSTOMER:	
MACHINE:	GENERAL MACHINERY
SHEET TITLE:	OVERLOAD INTEGRATION
PUB. DATE:	4/20/21
VERSION:	v0.1
SHEET NO.:	